



vehicle application list version 2.0.0





EOBD/OBDII Application

Make	From	Harness Required
Petrol vehicles	2000/2001	YTD950
Diesel vehicles	2004	YTD950

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Alfa Romeo	145	94 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	146	94 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	147	00 - 07	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC, Bosch 8 ABS, Bosch 8 ASR, Bosch 8 VDC	YTD951 B1
Alfa Romeo	155	95 - 97	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	156	97 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	156 '02	02 - 05	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC	YTD958 or YTD951 B1
Alfa Romeo	159	05 -	TRW / Lucas ABS	YTD951 B1
Alfa Romeo	164	88 - 98	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	166	98 - 03	Bosch 5.3 ABS, Bosch 5.3 TC ABS, Bosch 5.7 VDC	YTD958 or YTD951 B1
Alfa Romeo	33	88 - 89	Bosch 5.3 ASR ABS	YTD958 or YTD951 B1
Alfa Romeo	GT	04 -	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 8 ABS, Bosch 8 VDC	YTD951 B1
Alfa Romeo	GTV	95 - 03	Bosch 5.3 ABS	YTD958 or YTD951 B1
Alfa Romeo	Spider	95 - 03	Bosch 5.3 ABS	YTD958 or YTD951 B1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	98 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87) - 4 Cylinder	04 - 03/07	Teves MK 60E	YTD960
BMW	1 Series (E81/E87) - 6 Cylinder	04 - 03/07	Teves MK 60E5	YTD960
BMW	1 Series (E81/E87) - 4 Cylinder	03/07 -	Teves MK 60E (CAN)	YTD950 or YTD960
BMW	1 Series (E81/E87) - 6 Cylinder	03/07 -	Teves MK 60E5 (CAN)	YTD950 or YTD960
BMW	3 Series (E36)	90 - 98	ABS uC 3 Channel, ABS ASC ITT, ABS/ASC 5, Bosch ABS DSC3, Teves MK 20	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E46)	98 - 05	ABS/DSC 5.7, Teves MK 20, Teves MK 60, Teves DSC III MK 60	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E90/E91/E92/E93) - 4 Cylinder	05 - 03/07	Teves MK 60E	YTD960
BMW	3 Series (E90/E91/E92/E93) - 6 Cylinder	05 - 03/07	Teves MK 60E5	YTD960
BMW	3 Series (E90/E91/E92/E93) - AWD	05 - 03/07	Bosch ABS DSCS8 Plus	YTD960
BMW	3 Series (E90/E91/E92/E93) - 4 Cylinder	03/07 -	Teves MK 60E (CAN)	YTD960

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
BMW	3 Series (E90/E91/E92/E93) - 6 Cylinder	03/07 -	Teves MK 60E5 (CAN)	YTD960
BMW	3 Series (E90/E91/E92/E93) - AWD	03/07 -	Bosch ABS DSCS8 Plus (CAN)	YTD960
BMW	5 Series (E39)	96 - 04	ABS/ASC 5, ABS/ASC 5.7, ABS/DSC 5.7	YTD957 or YTD951 A6 / YTD960
BMW	5 Series (E60/E61)	04 - 09/05	Bosch ABS DSC8	YTD960
BMW	5 Series (E60/E61)	09/05 - 03/07	Bosch ABS DSCS8 Plus	YTD960
BMW	M5 (E60)	04 - 03/07	Teves MK 60E5	YTD960
BMW	5 Series (E60/E61)	03/07 -	Bosch ABS DSC8 (CAN)	YTD950 or YTD960
BMW	5 Series (E60/E61)	03/07 -	Bosch ABS DSCS8 Plus (CAN)	YTD950 or YTD960
BMW	M5 (E60)	03/07 -	Teves MK 60E5 (CAN)	YTD950 or YTD960
BMW	6 Series (E63/E64)	05 - 09/05	Bosch ABS DSC8	YTD960
BMW	6 Series (E63/E64)	09/05 - 03/07	Bosch ABS DSCS8 Plus	YTD960
BMW	M6 (E63/E64)	05 - 03/07	Teves MK 60E5	YTD960
BMW	6 Series (E63/E64)	03/07 -	Bosch ABS DSC8 (CAN)	YTD950 or YTD960
BMW	6 Series (E63/E64)	03/07 -	Bosch ABS DSCS8 Plus (CAN)	YTD950 or YTD960
BMW	M6 (E63/E64)	03/07 -	Teves MK 60E5 (CAN)	YTD950 or YTD960
BMW	7 Series (E38)	94 - 02	ABS 5, ABS/ASC 5, BOSCH ABS DSC3	YTD957 or YTD951 A6 / YTD960
BMW	7 Series (E65)	02 - 03/07	ABS/DSC5.7	YTD960
BMW	7 Series (E65)	03/07 -	ABS/DSC5.7 (CAN)	YTD960
BMW	8 Series (E31)	90 - 99	ABS 5, ABS/ASC 5, BOSCH ABS DSC3	YTD957
BMW	X3 (E83)	03 -	DSC 8 X-Drive	YTD951 A6 / YTD960
BMW	X5 (E53)	00 - 09/03	ABS/DSC 5.7	YTD951 A6 / YTD960
BMW	X5 (E53)	09/03 -	DSC 8 X-Drive	YTD951 A6 / YTD960
BMW	X5 (E70)	06 -	Bosch ABS DSCS8 Plus (CAN), Bosch EHB 3	YTD950 or YTD960
BMW	X6 (E71)	08 -	Bosch ABS DSCS8 Plus (CAN), Bosch EHB 3	YTD950 or YTD960
BMW	Z3 (E36)	96 - 03	Bosch ABS DSC3, Teves MK 20	YTD957 or YTD951 A6 / YTD960
BMW	Z4 (E85/E86)	03 - 06	Teves DSC III MK 60, DSC MK60E5	YTD951 A6
BMW	Z4/Z4M (E85/E86)	06 -	Teves DSC III MK 60, DSC MK60E5	YTD951 A6
BMW	Z8 (E52)	00 - 03	ABS/DSC 5.7	YTD957 or YTD951 A6 / YTD960
Citroen	Berlingo	96 - 04	Bosch 5.0 / 5.3 ABS	YTD953 or YTD951 J6
Citroen	C1	05 - 05	Bosch 8 ESP	YTD953 or YTD951 J6
Citroen	C2	03 - 05	Teves MK60 / MK70	YTD953 or YTD951 J6
Citroen	C3	02 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	C4	04 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	C5	00 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	C8	02 - 05	Bosch 5.7 ESP / Teves MK60	YTD953 or YTD951 J6
Citroen	Dispatch/Jumpy	95 - 02	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Evasion	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Relay/Jumper	97 - 02	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Saxo	98 - 03	Teves MK 20E/IE ABS / Teves 4-GI (ITT 04-GI) ABS	YTD953 or YTD951 J6
Citroen	Synergie	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Xantia	98 - 02	Bosch 5.3 ABS / Teves MK 20E/IE ABS	YTD953 or YTD951 J6
Citroen	XM	96 - 01	Teves MK 20E/IE ABS	YTD953 or YTD951 J6
Citroen	Xsara	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Citroen	Xsara Picasso	99 - 03	Bosch 5.3 ABS / Bosch 5.7 ESP	YTD953 or YTD951 J6
Fiat	Barchetta	96 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Fiat	Coupe	96 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Croma	93 - 96	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Croma '05	05 -	TRW / Lucas ABS	YTD951 B1
Fiat	Ducato	94 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Ducato RST	01 -	Bosch 5.3 ABS, Bosch 5.3 ASR ABS	YTD951 B1
Fiat	Idea	01 -	Bosch 5.3 ABS, Bosch 5.3 ASR ABS, Bosch 8 ABS, Bosch 8 VDC	YTD951 B1
Fiat	Marea/Weekend	96 - 99	Lucas ABS	YTD958 or YTD951 B1
Fiat	Multipla	98 - 01	Bosch 5.3 ABS, Bosch 5.7 VDC ABS	YTD958 or YTD951 B1
Fiat	Multipla '02	02 -	Bosch 5.3 ABS, Bosch 5.7 VDC ABS	YTD951 B1
Fiat	Palio	97 - 01	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Palio RST	01 - 02	Bosch 5.3 ABS	YTD951 B1
Fiat	Palio RST2	02 -	Bosch 5.3 ABS	YTD951 B1
Fiat	Panda 03	03 -	Bosch 8 ABS, Bosch 8 VDC ABS	YTD951 B1
Fiat	Punto	93 - 99	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Punto '99	99 - 03	Bosch 5.3 ABS, Bosch 5.3 TC ABS	YTD958 or YTD951 B1
Fiat	Punto '03	03 - 05	Bosch 5.3 ABS, Bosch 8 ABS, Bosch 8 VDC ABS	YTD958 or YTD951 B1
Fiat	Scudo	97 - 01	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Seicento	98 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Fiat	Stilo	01 -	Bosch 5.7 ABS, Bosch 5.7 VDC, Bosch 5.7 ABS/ASR/TC, Bosch 8 ABS, Bosch 8 VDC	YTD951 B1
Fiat	Ulysse	97 - 02	Bosch 5.3 ABS	YTD951 B1
Fiat	Ulysse '02	02 - 05	Bosch 5.7 ABS	YTD951 B1
Ford	Cougar	99 - 02	ABS	YTD950 or YTD960
Ford	Crown Victoria	95 - 07	ABS	YTD950 or YTD960
Ford	Escort	95 - 02	ABS	YTD950 or YTD960
Ford	Excursion	00 -	ABS	YTD950 or YTD960
Ford	Expedition	97 -	ABS	YTD950 or YTD960
Ford	Explorer	96 -	ABS	YTD950 or YTD960
Ford	E-Series	97 - 08	ABS	YTD950 or YTD960
Ford	F-250 Light Duty	97 - 02	ABS	YTD950 or YTD960
Ford	Fiesta	96 - 07	ABS	YTD950 or YTD960
Ford	Fiesta	08 -	ABS	YTD950 or YTD960
Ford	Focus	99 -	ABS	YTD950 or YTD960
Ford	Focus C-MAX	02 -	ABS	YTD950 or YTD960
Ford	Fusion	02 -	ABS	YTD950 or YTD960
Ford	F-Series Super Duty	97 -	ABS	YTD950 or YTD960
Ford	Galaxy	00 - 06	ABS	YTD950 or YTD960
Ford	Galaxy	06 -	ABS	YTD950 or YTD960
Ford	Granada/Scorpio	94 - 98	ABS	YTD950 or YTD960
Ford	GT	05 - 06	ABS	YTD950 or YTD960
Ford	Ka	96 - 08	ABS	YTD950 or YTD960
Ford	Street Ka	03 - 08	ABS	YTD950 or YTD960
Ford	Kuga	08 -	ABS	YTD950 or YTD960
Ford	Maverick	01 - 04	ABS	YTD950 or YTD960
Ford	Maverick 05	05 -	ABS	YTD950 or YTD960

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Ford	Mondeo III	95 - 06	ABS	YTD950 or YTD960
Ford	Mondeo IV	07 -	ABS	YTD950 or YTD960
Ford	Puma	97 - 01	ABS	YTD950 or YTD960
Ford	Ranger	99 - 06	ABS	YTD950 or YTD960
Ford	S-Max	06 -	ABS	YTD950 or YTD960
Ford	Transit	00 - 06	ABS	YTD950 or YTD960
Ford	Transit	06 -	ABS	YTD950 or YTD960
Ford	Transit / Torneo Connect	02 -	ABS	YTD950 or YTD960
Ford	WindStar	96 - 04	ABS	YTD950 or YTD960
GM	Agila	00 - 08	Agila ABS	YTD951 A2
GM	Astra-F	92 - 97	Bosch 2E	YTD951 J2
GM	Astra-G	98 - 04	Bosch 5.3/5.4TC, ESP	YTD951 A2
GM	Astra-H	04 -	Astra-H ABS/TC/ESP	YTD950 or YTD960
GM	Calibra	90 - 97	Bosch 2E	YTD951 J2
GM	Combo	02 - 06	Bosch5.3/5.4TC, Bosch 8	YTD951 A2/J2
GM	Corsa-B	97 - 01	Bosch 5.3	YTD951 J2
GM	Corsa-C	01 - 06	Bosch5.3/5.4TC, Bosch 8	YTD951 A2/J2
GM	Corsa-D	06 -	Corsa-D ABS/TC/ESP	YTD950 or YTD960
GM	Frontera-A	95 - 98	Bosch 415	YTD951 J2
GM	Movano	04 - 06	ABS 430	YTD951 A2
GM	Meriva	03 - 08	Bosch 8	YTD951 A2
GM	Omega-B	94 - 03	Bosch 2SH, Bosch 5.3/5.4TC, ESP	YTD951 A2/J2
GM	Signum	01 -	EBC430 ABS/TC/ESP	YTD950 or YTD960
GM	Speedster / VX220	01 - 06	KH430	YTD951 J2
GM	Tigra-A	95 - 00	ABS 4/4F, Bosch 5.3	YTD951 J2
GM	Tigra-B	05 - 08	Bosch 8	YTD951 A2
GM	Vectra-B	96 - 01	Bosch 415, Bosch 5 TC, KH430, Bosch5.3/5.4TC	YTD951 J2
GM	Vectra-C	01 -	EBC430 ABS/TC/ESP	YTD950 or YTD960
GM	Vivaro	01 - 06	ABS 430	YTD951 A2
GM	Zafira-A	99 - 05	Bosch5.3/5.4TC, Bosch 8	YTD951 A2
GM	Zafira-B	05 -	Zafira-B ABS/TC/ESP	YTD950 or YTD960
Lancia	Dedra	94 - 99	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Delta	96 - 00	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Kappa	94 - 01	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Lybra	99 - 06	Bosch 5.3 ABS, Bosch 5.3 ASR ABS, TRW Lucas ESP ABS	YTD958 or YTD951 B1
Lancia	Musa	04 - 06	Bosch 8 ABS, Bosch 8 VDC ABS	YTD951 B1
Lancia	Phedra	02 - 06	Bosch 5.7 ABS, Bosch 5.7 ESP	YTD951 B1
Lancia	Thesis	02 - 06	TRW / Lucas ABS	YTD951 B1
Lancia	Y	96 - 03	Bosch 5.3 ABS	YTD958 or YTD951 B1
Lancia	Ypsilon	03 - 06	TRW / Lucas ABC, TRW / Lucas ESP ABS	YTD951 B1
Lancia	Z	96 - 02	Bosch 5.3 ABS	YTD958 or YTD951 B1
Land Rover	Defender	99 - 03	Wabco D	YTD951 A1
Land Rover	Freelander	98 - 01	Wabco D	YTD951 A1
Land Rover	Freelander	01 - 06	ABS Mk25	YTD951 K2
Land Rover	Freelander II (L359)	07 -	Teves MK23 E1	YTD950 or YTD960

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Land Rover	Discovery II	99 - 04	Wabco D	YTD951 A1
Land Rover	Discovery III (L319)	05 -	Bosch 8	YTD950 or YTD960
Land Rover	Range Rover (P38a)	99 - 03	Wabco D	YTD951 A1
Land Rover	Range Rover (L322)	07 -	Bosch 8	YTD950 or YTD960
Land Rover	Range Rover Sport (L320)	05 -	Bosch 8	YTD950 or YTD960
Mercedes	A Class (W168)	98 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	A Class (W169)	04 -	ESP 169	YTD950
Mercedes	B Class (W245)	05 -	ESP 169	YTD950
Mercedes	C Class (W202)	93 - 01	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	C Class (W203)	00 - 09/03	ESP Mk25	YTD951 G2
Mercedes	C Class (W203)	09/03 - 07	ESP Mk25 (CAN)	YTD950
Mercedes	CL Class (W215)	99 - 06	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	CLK (W208)	98 - 02	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	CLK (W209)	02 - 04/04	ESP Mk25	YTD951 G2
Mercedes	CLK (W209)	04/04 - 02	ESP Mk25 (CAN)	YTD950
Mercedes	CLS (W219)	04 -	SBC/ESP	YTD950
Mercedes	CLS (W219)	04 -	SBC (CAN)	YTD950
Mercedes	E Class (W210)	95 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	E Class (W211)	02 -	EHF FSG	YTD951 G2
Mercedes	E Class (W211)	02 -	Sensotronic BC	YTD951 G2
Mercedes	E Class (W211)	02 -	SBC/ESP	YTD950
Mercedes	E Class (W211)	02 -	SBC (CAN)	YTD950
Mercedes	G Class (W461)	98 - 02	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	G Class (W463)	98 -	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	M Class (W163)	95 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	M Class (W164)	05 -	ESP164	YTD950
Mercedes	R Class (251)	05 -	ESP164	YTD950
Mercedes	S Class (W140)	91 - 08	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	S Class (W220)	98 - 05	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	S Class (W221)	05 -	ABR	YTD950
Mercedes	SL (R129)	93 - 03	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	EHF FSG	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	Sensotronic BC	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	SBC/ESP	YTD950
Mercedes	SL (R230)	03 - 06	SBC (CAN)	YTD950
Mercedes	SLK (R170)	91 - 04	ABS / ASR / ETS/ ESP / BAS*	YTD951 G2 and/or YTD956
Mercedes	SLK (R171)	04 -	ESP Mk25 (CAN)	YTD950
Mercedes	SLR (199)	04 -	EHF FSG	YTD951 G2
Mercedes	SLR (199)	04 -	Sensotronic BC	YTD951 G2
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	ABS / ASR / ETS/ ESP	YTD951 G2 and/or YTD955
*For BAS (if present) try switch positions G2, D2, F2				
MINI	MINI (R50 / R52 / R53)	00 - 07	Teves MK 60, Teves DSC III MK 60	YTD951 A6
MINI	MINI (R55 / R56 / R57)	06 -	TRW EBC 450	YTD950 or YTD960
Peugeot	1007	04 - 05	Teves MK60	YTD953 or YTD951 J6

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Peugeot	106	96 - 04	Teves 4-GI (ITT 04-GI) ABS / Teves MK 20E/IE ABS	YTD953 or YTD951 J6
Peugeot	107	05 - 05	Bosch 8 ESP	YTD953 or YTD951 J6
Peugeot	206	98 - 05	Teves MK 20E/IE ABS / Teves MK60 / Teves MK70	YTD953 or YTD951 J6
Peugeot	306	93 - 02	Bosch 5.0 ABS / Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	307	01 - 07	Bosch 5.3 ABS / Bosch 5.7 ESP / Bosch 8 ESP	YTD953 or YTD951 J6
Peugeot	406	95 - 03	Bosch 5.0 ABS / Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	605	96 - 00	Bosch 5.0 ABS / Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	607	00 - 03	Bosch 5.3 ABS / Bosch 5.7 ESP	YTD953 or YTD951 J6
Peugeot	806	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	807	02 - 05	Bosch 5.7 ESP	YTD953 or YTD951 J6
Peugeot	Boxer	97 - 01	Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	Expert	97 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Peugeot	Partner / Ranch	96 - 03	Bosch 5.3 ABS	YTD953 or YTD951 J6
Renault	Clio		Bosch 5.0 / Bosch 5.3/5.3T	YTD951 A1
Renault	Megane	98-03	Bosch 5.0 / Bosch 5.3/5.3T	YTD951 A1
Renault	Megane II	03 -	ABS 8 v3.0	YTD950
Renault	Kangoo	01 -	Bosch 8 ESP	YTD951 A1
Renault	Laguna	98 - 01	Bosch 5.3/5.3T / Teves MK 20	YTD951 A1
Renault	Laguna II	99-03	Teves MK 60	YTD951 A1
Renault	Scenic	98-03	Bosch 5.0 / Bosch 5.3/5.3T	YTD951 A1
Renault	Scenic II	03 -	ABS 8 v3.0	YTD950
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950
Skoda	Superb	02 -	KWP1281 / KW2000	YTD952 or YTD951 A1
Volvo	C70 Convertible/Coupe	99 - 05	ABS 1.1	YTD950
Volvo	S40	04 - 06	ABS 2	YTD950
Volvo	V50	03 - 08	ABS 2	YTD950
Volvo	S60	01 - 05	ABS 1	YTD950
Volvo	S70	99 - 00	ABS 1	YTD950
Volvo	V70	99 - 00	ABS 1	YTD950
Volvo	V70	00 - 07	ABS 2	YTD950
Volvo	XC70	99 - 00	ABS 1	YTD950
Volvo	XC70	00 - 06	ABS 2	YTD950
Volvo	S80	99 - 06	ABS 2	YTD950

FASTCHECK ABS

Make	Model	From/To	System	Harness Required
Volvo	XC90	02 - 06	ABS 2	YTD950
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281/KW2000	YTD950
VW	Golf/GTI	92 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Alfa Romeo	145	94 - 98	TRW2	YTD958 or YTD951 D1
Alfa Romeo	145	94 - 00	TRW MY97	YTD958 or YTD951 D1
Alfa Romeo	146	94 - 98	TRW2	YTD958 or YTD951 D1
Alfa Romeo	146	95 - 00	TRW MY97	YTD958 or YTD951 D1
Alfa Romeo	147	00 - 04	Allied MY97	YTD951 D1
Alfa Romeo	147	00 - 07	Siemens MY99	YTD951 D1
Alfa Romeo	156	97 - 02	Allied MY97, Allied Signal, Allied Signal 2	YTD958 or YTD951 D1
Alfa Romeo	156 '02	02 - 05	Siemens MY99	YTD951 D1
Alfa Romeo	159	05 -	TRW MY03	YTD950 or YTD959
Alfa Romeo	166	98 - 03	TRW MY97, TRW MY99	YTD958 or YTD951 D1
Alfa Romeo	GT	04 -	Siemens MY99	YTD951 D1
Alfa Romeo	GTV	95 - 98	TRW2 Airbag w/pretensioners	YTD958 or YTD951 D1
Alfa Romeo	GTV	97 - 03	TRW MY97	YTD958 or YTD951 D1
Alfa Romeo	Spider	95 - 98	TRW2 Airbag w/pretensioners	YTD958 or YTD951 D1
Alfa Romeo	Spider	97 - 03	TRW MY97	YTD958 or YTD951 D1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	95 - 04	KWP1281/KW2000	YTD952
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	98 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87)	04 - 03/07	MRS5	YTD960
BMW	1 Series (E81/E87)	03/07 -	MRS5 (CAN), ACSM (CAN)	YTD960
BMW	3 Series (E30)	91 - 93	Driver Airbag (5WK4 060)	YTD957
BMW	3 Series (E36)	90 - 98	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E36)	91 - 93	Driver Airbag (5WK4 060)	YTD957
BMW	3 Series (E36)	93 - 95	1 or 2 airbags (ZAE, BAE)	YTD957
BMW	3 Series (E46)	98 - 05	MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	MRS5	YTD960
BMW	3 Series (E90/E91/E92/E93)	06 - 03/07	ACSM	YTD960
BMW	3 Series (E90/E91/E92/E93)	03/07 -	MRS5 (CAN)	YTD960
BMW	5 Series (E34)	91 - 93	Driver Airbag (5WK4 060)	YTD957

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
BMW	5 series (E34)	93 - 95	1 or 2 airbags (ZAE, BAE)	YTD957
BMW	5 Series (E39)	96 - 04	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	5 Series (E60/E61)	04 - 03/07	ACSM	YTD960
BMW	5 Series (E60/E61)	03/07 -	MRS6	YTD950 or YTD960
BMW	6 Series (E63/E64)	05 - 03/07	ACSM	YTD960
BMW	6 Series (E63/E64)	03/07 -	MRS6	YTD950 or YTD960
BMW	7 Series (E32)	91 - 93	Driver Airbag (5WK4 060)	YTD957
BMW	7 Series (E38)	94 - 02	ZAE BAE, ZAE2, MRS 1, MRS 2, MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	7 Series (E65)	02 - 03/07	Multi-bag system	YTD950 or YTD960
BMW	8 series (E31)	93 - 95	1 or 2 airbags (ZAE, BAE)	YTD957
BMW	8 Series (E31)	90 - 99	ZAE BAE, ZAE2, MRS 1, MRS 2	YTD957
BMW	X3 (E83)	03 -	MRS 4 Redesign	YTD951 A6 / YTD960
BMW	X5 (E53)	00 -	MRS 3, MRS 4	YTD951 A6 / YTD960
BMW	X5 (E70)	06 -	ACSM (CAN)	YTD950 or YTD960
BMW	X6 (E71)	08 -	ACSM (CAN)	YTD950 or YTD960
BMW	Z3 (E36)	96 - 03	MRS 3, MRS 4	YTD957 or YTD951 A6 / YTD960
BMW	Z4 (E85/E86)	06 -	ACSM	YTD951 A6 / YTD960
BMW	Z8 (E52)	00 - 03	MRS 3, MRS 4	YTD957 or YTD951 A6
Citroen	Berlingo	96 - 00	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Citroen	Berlingo	00 -	Autoliv ACU /TRW Airbag	YTD951 K2 or K9
Citroen	C2	03 -	Autoliv ACU	YTD951 K2 or K9
Citroen	C3	02 -	Temic SRS	YTD951 K2 or K9
Citroen	C4	04 -	Temic SRS	YTD951 K2 or K9
Citroen	C5	00 -	Temic SRS	YTD951 K2 or K9
Citroen	C8	02 -	Temic SRS	YTD951 K2 or K9
Citroen	Dispatch/Jumpy	95 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Dispatch/Jumpy	00 -	Autoliv ACU	YTD951 K2 or K9
Citroen	Evasion	95 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Evasion	00 -	Autoliv ACU	YTD951 K2 or K9
Citroen	Relay / Jumper	94 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Citroen	Saxo	96 - 00	Airbag / Seat Belt	YTD953 or YTD951 K2 or K9
Citroen	Saxo	00 - 03	Autoliv ACU	YTD951 K2 or K9
Citroen	Synergie	96 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Synergie	00 - 03	Autoliv ACU	YTD951 K2 or K9
Citroen	Xantia	96 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Citroen	Xantia	00 - 02	Autoliv ACU	YTD951 K2 or K9
Citroen	XM	96 - 98	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Citroen	XM	00 - 01	Autoliv ACU	YTD951 K2 or K9
Citroen	Xsara	00 -	Autoliv ACU	YTD951 K2 or K9
Citroen	Xsara Picasso	00 -	Autoliv ACU	YTD951 K2 or K9
Fiat	Barchetta	96 - 98	TRW2 Airbag w/pretensioners	YTD958 or YTD951 D1
Fiat	Barchetta	97 - 00	TRW MY97	YTD958 or YTD951 D1
Fiat	Bravo/Brava	95 - 00	Breed	YTD958 or YTD951 D1
Fiat	Bravo/Brava	97 - 02	Breed MY97	YTD958 or YTD951 D1
Fiat	Coupe	94 - 02	TRW2 , TRW MY97	YTD958 or YTD951 D1
Fiat	Croma '05	05 -	TRW MY03	YTD950 or YTD959

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Fiat	Doblo	00 - 05	Autoliv MY99	YTD951 D1
Fiat	Ducato	94 - 02	Breed Airbag w/pre-tensioners, Breed MY97, TRW MY99	YTD958 or YTD951 D1
Fiat	Ducato RST	01 -	Siemens MY99	YTD951 D1
Fiat	Idea	04 -	TRW MY03	YTD959
Fiat	Marea/Weekend	96 - 02	Allied Signal, Allied MY97, Breed MY97	YTD958 or YTD951 D1
Fiat	Multipla	98 - 01	Breed 97	YTD958 or YTD951 D1
Fiat	Multipla	02 -	Siemens MY99	YTD951 D1
Fiat	Palio	97 - 01	TRW2, TRW MY97	YTD958 or YTD951 D1
Fiat	Palio RST	01 - 02	TRW MY97	YTD951 D1
Fiat	Palio RST 2	02 -	TRW MY97	YTD951 D1
Fiat	Panda 03	03 -	TRW MY99	YTD951 D1
Fiat	Punto	93 - 99	TRW2, TRW MY97	YTD958 or YTD951 D1
Fiat	Punto '99	99 - 03	TRW MY97	YTD958 or YTD951 D1
Fiat	Punto '03	03 - 05	TRW MY97, TRW MY99	YTD951 D1
Fiat	Scudo	96 - 04	Autoliv ACU, Autoliv Central Airbags	YTD953 or YTD951 K2 or K9
Fiat	Seicento	98 - 04	TRW MY97	YTD958 or YTD951 D1
Fiat	Stilo	01 - 05	Siemens MY99	YTD951 D1
Fiat	Ulysse	95 - 02	Autoliv Central Airbags, Autoliv side airbags	YTD953 or YTD951 K2 or K9
Fiat	Ulysse '02	02 - 05	Temic SRS	YTD953 or YTD951 K2 or K9
Ford	Cougar	99 - 02	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Crown Victoria	96 - 98	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Crown Victoria	98 - 07	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Crown Victoria	00 - 07	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Escort	95 - 02	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Expedition	97 - 99	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Expedition	99 - 08	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Explorer	96 - 06	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	Explorer	00 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Excursion	00 - 05	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Excursion	05 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	E-Series	97 - 05	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	E-Series	05 - 08	RCM - Restraint Control Module	YTD950 or YTD960
Ford	F-250 Light Duty	97 - 99	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	F-250 Light Duty	99 - 02	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Fiesta	99 - 07	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Fiesta	02 - 07	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Fiesta	08 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Focus	99 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Focus	99 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Focus C-MAX	02 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Focus C-MAX	02 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	F-Series Super Duty	99 - 02	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	F-Series Super Duty	01 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Galaxy	99 - 06	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Galaxy	06 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	GT	05 - 06	RCM - Restraint Control Module	YTD950 or YTD960

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Ford	Fusion	02 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Ka	96 - 08	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Street Ka	03 - 08	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	Kuga	08 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Maverick	01 - 04	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Maverick 05	05 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Mondeo III	01 - 06	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Mondeo IV	07 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Ranger	06 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	S-Max	06 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Transit	00 - 06	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Transit	06 -	RCM - Restraint Control Module	YTD950 or YTD960
Ford	Transit / Torneo Connect	02 -	ECS - Electronic Crash Sensor	YTD950 or YTD960
Ford	WindStar	96 - 98	IABM - Integrated Airbag Module	YTD950 or YTD960
Ford	WindStar	99 - 04	RCM - Restraint Control Module	YTD950 or YTD960
GM	Agila	00 - 08	Agila SRS	YTD951 A2
GM	Astra F	94 - 98	Airbag S	YTD951 J7
GM	Astra-G	98 - 04	Airbag SAB6	YTD951 J7
GM	Astra-H	04 -	Astra-H SDM Airbag	YTD960
GM	Calibra	93 - 97	Airbag S	YTD951 J7
GM	Cavalier	93 - 95	Airbag S	YTD951 J7
GM	Combo	02 - 06	Airbag 20	YTD951 F2
GM	Corsa-B	94 - 01	Airbag S	YTD951 J7
GM	Corsa-B	94 - 01	Airbag SAB6	YTD951 J7
GM	Corsa-C	01 - 06	Airbag 20	YTD951 F2
GM	Corsa-D	06 -	Corsa-D SDM Airbag	YTD960
GM	Frontera-A	97 - 98	Airbag SDM (5V)	YTD951 G2
GM	Frontera-B	99 - 02	Airbag SDM (5V)	YTD951 G2
GM	Meriva	03 - 08	Airbag 20	YTD951 F2
GM	Monterey	97 - 98	Airbag SDM (5V)	YTD951 G2
GM	Omega-B	94 - 99	Airbag S	YTD951 J7
GM	Omega-B	94 - 01	Airbag SAB6	YTD951 J7
GM	Omega-B	01 - 03	Airbag 20	YTD951 F2
GM	Signum	01 -	Signum SDM Airbag	YTD960
GM	Speedster / VX220	01 - 06	Airbag	YTD951 J7
GM	Tigra-A	95 - 99	Airbag S	YTD951 J7
GM	Tigra-B	05 - 08	Airbag 20	YTD951 F2
GM	Vectra-A	93 - 95	Airbag S	YTD951 J7
GM	Vectra-B	95 - 01	Airbag SAB6	YTD951 J7
GM	Vectra-B	95 - 01	Airbag SAE4	YTD951 J7
GM	Vectra-B	95 - 01	Airbag	YTD951 J7
GM	Vectra-C	01 -	Vectra-C SDM Airbag	YTD960
GM	Vivaro	01 - 06	Airbag ACU3	YTD951 A2
GM	Zafira-A	99 - 05	Airbag SAB6	YTD951 J7
GM	Zafira-B	05 -	Zafira-B SDM Airbag	YTD960
Lancia	Kappa	94 - 01	TRW2 Airbag w/pretensioners, TRW MY97	YTD958 or YTD951 D1

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Lancia	Lybra	99 - 06	Allied MY97, Siemens MY99	YTD958 or YTD951 D1
Lancia	Musa	04 - 06	TRW MY03	YTD959
Lancia	Phedra	02 - 06	Temic SRS	YTD953 or YTD951 K2 or K9
Lancia	Thesis	02 - 06	TRW MY99	YTD951 D1
Lancia	Y	96 - 03	Allied Signal, Allied MY97	YTD958 or YTD951 D1
Lancia	Ypsilon	03 - 06	Autoliv MY99	YTD951 D1
Lancia	Z	96 - 02	Autoliv, Autoliv ACU	YTD953 or YTD951 K2 or K9
Land Rover	Freelander	98 - 02	Autoliv AC4	YTD951 A1
Land Rover	Freelander	03 - 06	Siemens SRE Smart	YTD951 A1
Land Rover	Freelander II (L359)	07 -	RCM - Restraint Control Module	YTD950 or YTD960
Land Rover	Discovery	96 - 98	TRW SPS	YTD951 L11
Land Rover	Discovery II	98 - 04	TRW Generation 4	YTD951 A1
Land Rover	Discovery III (L319)	05 -	RCM - Restraint Control Module	YTD950 or YTD960
Land Rover	Range Rover (P38a)	97 - 02	TRW SPS	YTD951 L11
Land Rover	Range Rover (L322)	03 -	Bosch MRS4	YTD951 F2
Land Rover	Range Rover Sport (L320)	05 -	RCM - Restraint Control Module	YTD950 or YTD960
Mercedes	A Class (W168)	98 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	A Class (W169)	04 -	AB 169	YTD950
Mercedes	B Class (W245)	05 -	AB 169	YTD950
Mercedes	C Class (W202)	93 - 01	Fast Codes	YTD951 B2 or K2
Mercedes	C Class (W203)	00 - 09/03	Arminca	YTD951 B2 or K2
Mercedes	C Class (W203)	09/03 - 07	Armada	YTD950
Mercedes	C Class (W203)	09/03 - 07	WSS	YTD950
Mercedes	CL Class (W215)	99 - 09/02	Armin	YTD951 B2 or K2
Mercedes	CL Class (W215)	09/02 - 06	Armada 2	YTD950
Mercedes	CLK (W208)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	CLK (W209)	02 - 04/04	Arminca	YTD950
Mercedes	CLK (W209)	04/04 - 02	Armada	YTD950
Mercedes	CLK (W209)	04/04 - 02	WSS	YTD950
Mercedes	CLS (W219)	04 -	Armada	YTD950
Mercedes	CLS (W219)	04 -	RGSL 211	YTD950
Mercedes	CLS (W219)	04 -	RGSR 211	YTD950
Mercedes	CLS (W219)	04 -	WSS	YTD950
Mercedes	E Class (W210)	95 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	E Class (W211)	02 -	Armada	YTD950
Mercedes	E Class (W211)	02 -	RGSL 211	YTD950
Mercedes	E Class (W211)	02 -	RGSR 211	YTD950
Mercedes	E Class (W211)	02 -	WSS	YTD950
Mercedes	G Class (W461)	98 - 02	Fast Codes	YTD951 B2 or K2
Mercedes	G Class (W463)	98 -	Fast Codes	YTD950
Mercedes	G Class (W463)	98 -	Armin	YTD950
Mercedes	M Class (W163)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	M Class (W164)	05 -	Arcade 164	YTD950
Mercedes	M Class (W164)	05 -	RGSL 164	YTD950
Mercedes	M Class (W164)	05 -	RGSR 164	YTD950
Mercedes	M Class (W164)	05 -	WSS	YTD950

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Mercedes	R Class (251)	05 -	Arcade 164	YTD950
Mercedes	R Class (251)	05 -	RGSL 164	YTD950
Mercedes	R Class (251)	05 -	RGSR 164	YTD950
Mercedes	R Class (251)	05 -	WSS	YTD950
Mercedes	S Class (W140)	91 - 08	Fast Codes	YTD951 B2 or K2
Mercedes	S Class (W220)	98 - 09/02	Fast Codes	YTD950
Mercedes	S Class (W220)	09/02 -	Armada 2	YTD950
Mercedes	S Class (W220)	09/02 -	REVASL	YTD950
Mercedes	S Class (W220)	09/02 -	REVASR	YTD950
Mercedes	S Class (W221)	05 -	Arcade 221	YTD950
Mercedes	S Class (W221)	05 -	RGSL 221	YTD950
Mercedes	S Class (W221)	05 -	RGSR 221	YTD950
Mercedes	S Class (W221)	05 -	WSS 221	YTD950
Mercedes	SL (R129)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	SL (R230)	03 - 06	Armada 2	YTD950
Mercedes	SLK (R170)	93 - 03	Fast Codes	YTD951 B2 or K2
Mercedes	SLK (R171)	04 -	Armada	YTD950
Mercedes	SLR (199)	04 -	Armada 2	YTD950
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	Fast Codes	YTD951 B2 or K2 and YTD955
Mercedes	Vaneo (414)	02 -	Armin	YTD951 B2 or K2
Mercedes	Viano (639)	03 -	Armada	YTD951 B2 or K2
Mercedes	Vito (639)	03 -	Armada	YTD951 B2 or K2
MINI	MINI (R50 / R53)	00 - 07	MRS 4	YTD951 A6
MINI	MINI (R55 / R56 / R57)	06 -	MRS 6	YTD950 or YTD960
Peugeot	1007	04 - 06	TRW Airbag	YTD951 K2 or K9
Peugeot	106	96 - 00	Airbag / Seat Belt	YTD953 or YTD951 K2 or K9
Peugeot	106	00 - 04	Autoliv ACU	YTD951 K2 or K9
Peugeot	206	98 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	206	00 - 06	Autoliv ACU / Temic SRS	YTD951 K2 or K9
Peugeot	306	96 - 00	Airbag / Seat Belt / Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	306	00 - 02	Autoliv ACU	YTD951 K2 or K9
Peugeot	307	01 - 07	Temic SRS	YTD951 K2 or K9
Peugeot	406	95 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	406	00 - 03	Autoliv ACU	YTD951 K2 or K9
Peugeot	407	05 -	Temic SRS	YTD951 K2 or K9
Peugeot	605	97 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	607	01 - 06	Temic SRS	YTD951 K2 or K9
Peugeot	806	96 - 00	Airbag/ Seat Belt/ Side Airbags	YTD953 or YTD951 K2 or K9
Peugeot	806	00 - 03	Autoliv ACU	YTD951 K2 or K9
Peugeot	807	02 -	Temic SRS	YTD951 K2 or K9
Peugeot	Boxer	96 - 00	Breed SRS / Breed 97 MY / Siemens 99 MY	Use Fiat Ducato
Peugeot	Expert	97 - 00	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Peugeot	Expert	00 -	Autoliv ACU	YTD951 K2 or K9
Peugeot	Partner/Ranch	96 - 00	Airbag/ Seat Belt	YTD953 or YTD951 K2 or K9
Peugeot	Partner/Ranch	00 -	Autoliv ACU / TRW Airbag	YTD951 K2 or K9
Renault	Clio II	98 - 06	AB7	YTD951 A1

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
Renault	Clio II	98 - 06	AB8	YTD951 A1
Renault	Clio III	06 -	AB9	YTD950
Renault	Laguna	93 - 00	AC6	YTD951 A1
Renault	Laguna	93 - 00	AC6 Phase 2	YTD951 A1
Renault	Laguna	93 - 00	EC5	YTD951 A1
Renault	Megane	95 - 02	AC4	YTD951 A1
Renault	Megane	95 - 02	AC4 Phase 2	YTD951 A1
Renault	Megane	95 - 02	AC6	YTD951 A1
Renault	Megane	95 - 02	AC6 Phase 2	YTD951 A1
Renault	Megane	95 - 02	ACU 3.8	YTD951 A1
Renault	Megane II	02 -	Siemens Autoliv ACU4 MK2	YTD950
Renault	Modus	04 -	AB9	YTD950
Renault	Scenic	95 - 02	EC5	YTD951 A1
Renault	Scenic	95 - 02	AC4	YTD951 A1
Renault	Scenic	95 - 02	AC4 Phase 2	YTD951 A1
Renault	Scenic	95 - 02	AC6	YTD951 A1
Renault	Scenic	95 - 02	AC6 Phase 2	YTD951 A1
Renault	Scenic	95 - 02	EC5	YTD951 A1
Renault	Scenic II	03 -	Siemens Autoliv ACU4 MK2	YTD950
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Felicia	95 - 04	KWP1281 / KW2000	YTD951 A1
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950
Skoda	Superb	02 - 04	KWP1281 / KW2000	YTD951 A1
Volvo	S40	04 - 06	P1X	YTD960
Volvo	V50	03 - 08	P1X	YTD960
Volvo	S60	01 - 05	P2X	YTD960
Volvo	V70	00 - 07	P2X	YTD960
Volvo	XC70	00 - 06	P2X	YTD960
Volvo	S80	99 - 06	P2X	YTD960
Volvo	XC90	02 - 06	P2X	YTD960
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950

FASTCHECK AIRBAG

Make	Model	From/To	System	Harness Required
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281 / KW2000	YTD950
VW	Golf/GTI	91 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	93 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
Alfa Romeo	147	00 - 07	Delphi (Single Zone) Delphi (Dual Zone)	YTD959
Alfa Romeo	156	97 - 02	Harrison Climate Control	YTD951 G1
Alfa Romeo	159	05 -	Delphi (Single Zone) Delphi (Dual Zone)	YTD950 or YTD959
Alfa Romeo	GT	04 -	Delphi (Single Zone) Delphi (Dual Zone)	YTD959
Alfa Romeo	GTV	98 - 03	Harrison Climate Control	YTD951 G1
Alfa Romeo	Spider	98 - 03	Harrison Climate Control	YTD951 G1
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	92 - 02	KWP1281/KW2000	YTD952
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	98 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87)	04 - 03/07	IHR E87 / E90, IHKR E87 / E90, IHKA E87 / E90	YTD960
BMW	1 Series (E81/E87)	03/07 -	IHR E87 / E90 (CAN), IHKR E87 / E90 (CAN), IHKA E87 / E90 (CAN)	YTD950 or YTD960
BMW	3 Series (E36)	90 - 98	IHKA E36	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E46)	98 - 05	IHKR E46 / E83, IHKA E46 / E83	YTD957 or YTD951 A6 / YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	IHR E87 / E90, IHKR E87 / E90, IHKA E87 / E90	YTD960
BMW	3 Series (E90/E91/E92/E93)	03/07 -	IHR E87 / E90 (CAN), IHKR E87 / E90 (CAN), IHKA E87 / E90 (CAN)	YTD950 or YTD960
BMW	5 Series (E39)	96 - 04	IHR E39, IHKR E39 / E53, IHKA E39 / E53, IHKA E39	YTD957 or YTD951 A6 / YTD960
BMW	5 Series (E60/E61)	04 - 03/07	IHKA E60 / E63 / E65	YTD960
BMW	5 Series (E60/E61)	03/07 -	IHKA E60 / E63 / E65 (CAN), IHKA 2 E60 / E63	YTD950 or YTD960
BMW	6 Series (E63/E64)	05 - 03/07	IHKA E60 / E63 / E65	YTD960
BMW	6 Series (E63/E64)	03/07 -	IHKA E60 / E63 / E65 (CAN), IHKA 2 E60 / E63	YTD950 or YTD960
BMW	7 Series (E38)	94 - 02	IHKR E38, IHKA E38, FGB E38, FHK E38	YTD957 or YTD951 A6 / YTD960
BMW	7 Series (E65)	02 - 03/07	IHKA E60/E63/E65	YTD960
BMW	7 Series (E65)	03/07 -	IHKA E60 / E63 / E65 (CAN)	YTD950 or YTD960
BMW	X3 (E83)	03 -	IHKR E46 / E83, IHKA E46 / E83	YTD951 A6 / YTD960
BMW	X5 (E53)	00 -	IHKR E39 / E53, IHKA E39 / E53	YTD951 A6 / YTD960
BMW	X5 (E70)	06 -	IHKA E87/E90 (CAN)	YTD950 or YTD960
BMW	X6 (E71)	08 -	IHKA E87/E90 (CAN)	YTD950 or YTD960

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
BMW	Z3 (E36)	96 - 03	IHKA E36	YTD957 or YTD951 A6 / YTD960
BMW	Z4 (E85)	03 -	IHS/IHKS E85, IHKA E85	YTD951 A6 / YTD960
BMW	Z8 (E52)	00 - 03	IHKS E52	YTD957 or YTD951 A6 / YTD960
Citroen	C3	00 -	Behr	YTD951 I2
Citroen	C5	99 -	Valeo	YTD951 I2
Citroen	Xantia	99 -	Valeo	YTD951 I2
Citroen	Xsara	00 -	Behr	YTD951 I2
Fiat	Croma 05	05 -	Valeo Climate Control (Two Zone)	YTD950 or YTD959
Fiat	Idea	04 -	Denso Climate Control 1 (Two Zone)	YTD959
Fiat	Panda 03	03 - 05	Denso Climate Control 1 (Single Zone)	YTD959
Fiat	Punto 03	03 - 05	Denso 2 Climate Control (Two Zone)	YTD959
Fiat	Ulysse	95 - 02	Behr Climate Control	YTD951 I2
Ford	Crown Victoria	95 - 07	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Expedition	99 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Expedition	99 -	RCC - Remote Climate Control	YTD950 or YTD960
Ford	Explorer	94 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Fiesta	02 - 07	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Fiesta	08 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Focus	98 - 03	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Focus	04 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Focus C-MAX	02 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Fusion	02 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Galaxy	99 - 06	RCC - Remote Climate Control	YTD950 or YTD960
Ford	Galaxy	06 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Ka	00 - 08	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Kuga	08 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Mondeo	00 - 06	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Mondeo	07 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	S-Max	06 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Transit	00 - 06	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
Ford	Transit	06 -	EATC - Electronic Automatic Temperature Control	YTD950 or YTD960
GM	Astra-G	02 - 04		YTD951 J2
GM	Astra-H	04 -	ECC/SAC	YTD960
GM	Corsa-C	03 - 06		YTD951 J2
GM	Corsa-D	06 -	ECC/SAC	YTD960
GM	Corsa-D	06 -	HVA	YTD960
GM	Meriva	03 - 08		YTD951 J2
GM	Omega-B	94 - 99		YTD951 J2
GM	Omega-B	00 - 03		YTD951 J2
GM	Signum	01 -	ECC/SAC	YTD960
GM	Signum	01 -	HVA	YTD960
GM	Vectra-B	95 - 01		YTD951 J2
GM	Vectra-C	01 -	ECC/SAC	YTD960
GM	Vectra-C	01 -	HVA	YTD960
GM	Zafira-A	03 - 05		YTD951 J2

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
GM	Zafira-B	05 -	ECC/SAC	YTD960
Lancia	Musa	04 -	Denso 1 Climate Control (Two Zone)	YTD959
Lancia	Thesis	02 - 06	Borletti / Hella Climate Control	YTD959
Lancia	Ypsilon	03 - 06	Denso Climate Control (Two Zone)	YTD959
Lancia	Z	96 - 02	Behr Climate Control	YTD951 I2
Land Rover	Freelander II (L359)	07 -	Hevac	YTD960
Land Rover	Discovery III (L319)	05 -	Hevac	YTD960
Land Rover	Range Rover (P38a)	97 - 02	Hevac	YTD951 A1
Land Rover	Range Rover (L322)	03 - 06	Hevac	YTD951 F2
Land Rover	Range Rover (L322)	07 -	Hevac	YTD960
Land Rover	Range Rover Sport (L320)	05 -	Hevac	YTD960
Mercedes	A Class (W168)	98 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	A Class (W169)	04 -	KLA 169	YTD950
Mercedes	B Class (W245)	05 -	KLA 169	YTD950
Mercedes	C Class (W202)	93 - 01	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	C Class (W203)	00 - 09/03	KLA203	YTD951 B2/C2/J2 and/or YTD956
Mercedes	C Class (W203)	09/03 - 07	KLA203 (CAN)	YTD950
Mercedes	C Class (W203)	09/03 - 07	STH 211	YTD950
Mercedes	CL Class (W215)	99 - 06	KLA220	YTD951 B2/C2/J2 and/or YTD956
Mercedes	CL Class (W215)	09/02 - 06	STH 220	YTD950
Mercedes	CLK (W208)	98 - 02	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	CLK (W209)	02 -	KLA203	YTD951 B2/C2/J2 and/or YTD956
Mercedes	CLK (W209)	04/04 - 02	KLA203 (CAN)	YTD950
Mercedes	CLK (W209)	04/04 - 02	STH 211	YTD950
Mercedes	CLS (W219)	04 -	KLA 211	YTD950
Mercedes	CLS (W219)	04 -	STH 211	YTD950
Mercedes	E Class (W210)	95 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	E Class (W211)	02 -	KLA 211	YTD950
Mercedes	E Class (W211)	02 -	LRK 211	YTD950
Mercedes	E Class (W211)	02 -	STH 211	YTD950
Mercedes	G Class (W461)	98 - 02	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	G Class (W463)	98 - 04/04	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	G Class (W463)	04/04 -	KLA203 (CAN)	YTD950
Mercedes	G Class (W463)	04/04 -	STH 203	YTD950
Mercedes	M Class (W164)	05 -	KLA 164	YTD950
Mercedes	M Class (W164)	05 -	STH 164	YTD950
Mercedes	R Class (251)	05 -	KLA 164	YTD950
Mercedes	R Class (251)	05 -	STH 164	YTD950
Mercedes	S Class (W140)	95 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	S Class (W220)	99 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	S Class (W220)	09/02 -	STH 220	YTD950
Mercedes	S Class (W221)	05 -	KLA 221	YTD950
Mercedes	S Class (W221)	05 -	HVCR 221	YTD950
Mercedes	S Class (W221)	05 -	STH 221	YTD950
Mercedes	SL Class (R129)	95 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
Mercedes	SL (R230)	03 - 06	KLA230	YTD951 B2/C2/J2 and/or YTD956
Mercedes	SLK (R170)	98 - 03	KLA	YTD951 B2/C2/J2 and/or YTD956
Mercedes	SLK (R171)	04 -	KLA 171	YTD950
Mercedes	SLR (199)	04 -	KLA230	YTD951 B2/C2/J2 and/or YTD956
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	KLA	YTD951 B2/C2/J2 and/or YTD955
MINI	MINI (R50 / R53)	00 - 07	MINI IHKA	YTD951 A6
MINI	MINI (R55 / R56 / R57)	06 -	MINI IHS, MINI IHKS, MINI IHKA (CAN)	YTD950 or YTD960
Peugeot	206	00 -	Behr GKR	YTD951 E2
Peugeot	307	00 -	Behr	YTD951 I2
Peugeot	406	99 - 04	Valeo	YTD951 I2
Peugeot	607	99 -	Valeo	YTD951 I2
Renault	Laguna I	98 - 99	BEHR	YTD951 A1
Renault	Laguna II	99 - 05	Valeo 4	YTD951 A1
Renault	Laguna II	99 - 05	Valeo 5	YTD951 A1
Renault	Megane	00 - 03	J64	YTD951 A1
Renault	Megane II	03 -	Controlled AC	YTD950
Renault	Scenic	00 - 03	J64	YTD951 A1
Renault	Scenic II	03 -	Controlled AC	YTD950
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950
Skoda	Superb	02 -	KWP1281 / KW2000	YTD952 or YTD951 A1
Volvo	C70 Convertible/Coupe	99 - 05	CCM X70	YTD960
Volvo	S40	01 - 04	CCM 1	YTD960
Volvo	S40	04 - 06	CCM 2	YTD960
Volvo	V40	01 - 04	CCM 1	YTD960
Volvo	V50	03 - 08	CCM 2	YTD960
Volvo	S60	01 - 05	CCM 2	YTD960
Volvo	S70	99 - 00	CCM X70	YTD960
Volvo	V70	99 - 00	CCM X70	YTD960
Volvo	V70	00 - 07	CCM 2	YTD960
Volvo	XC70	00 - 06	CCM 2	YTD960
Volvo	S80	99 - 06	CCM 2	YTD960
Volvo	XC90	02 - 06	CCM 2	YTD960
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1

FASTCHECK CLIMATE CONTROL

Make	Model	From/To	System	Harness Required
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281 / KW2000	YTD950
VW	Golf/GTI	92 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950

FASTCHECK EPB - Electronic Parking Brake

Make	Model	From/To	System	Harness Required
Audi	A4	05 -	EPB	YTD950
Audi	A5	07 -	EPB	YTD950
Audi	A6	04 -	EPB	YTD950
Audi	S6	04 -	EPB	YTD950
Audi	A8	04 -	EPB	YTD950
Ford	C-Max	03 -	EPB	YTD950
Ford	Galaxy	06 -	EPB	YTD950
Ford	S-Max	06 -	EPB	YTD950
Land Rover	Discovery III (L319)	05 -	PBM	YTD950
Land Rover	Range Rover (L322)	07 -	PBM	YTD950
Land Rover	Range Rover Sport (L320)	05 -	PBM	YTD950
Mercedes	CLS (W219)	04 -	SBC (CAN)	YTD950
Mercedes	E Class (W211)	02 -	Sensotronic BC	YTD951 G2
Mercedes	E Class (W211)	02 -	SBC (CAN)	YTD950
Mercedes	SL (R230)	03 - 06	Sensotronic BC	YTD951 G2 and/or YTD956
Mercedes	SL (R230)	03 - 06	SBC (CAN)	YTD950
Mercedes	SLR (199)	04 -	Sensotronic BC	YTD951 G2
Renault	Megane II	03 -	EPB	YTD950
Renault	Scenic II	02 -	EPB	YTD950
Renault	Espace IV	02 -	EPB	YTD950
Renault	Vel Satis	01 -	EPB	YTD950
VW	Passat	05 -	EPB	YTD950
VW	Tiguan	07 -	EPB	YTD950

FASTCHECK SAS - Steering Angle Sensor

Make	Model	Body/Chassis	From/To	System	Harness Required
Audi	A2	8Z	01 -	ESP 20	YTD950
Audi	A2	8Z	01 -	ESP Front/Allrad MK60	YTD950
Audi	A3	8L	97 - 02	ESP 20	YTD950
Audi	A3	8L	02 - 03	ESP Front MK60	YTD950
Audi	A3	8P	04 -	ESP Front MK60	YTD950
Audi	A4	8D (B5)	97 - 00	ABS/ESP Front	YTD950
Audi	A4	8E, 8H (B6)	01 - 05	ABS/ESP Front	YTD950
Audi	A4	8E, 8H (B7)	05 -	ESP 8 Front	YTD950
Audi	A4 Cabriolet	8E, 8H (B6)	03 - 05	ABS/ESP Front	YTD950
Audi	A4 Cabriolet	8E, 8H (B7)	05 -	ESP 8 Front	YTD950
Audi	A4 Quattro	8D (B5)	97 - 00	ABS/ESP Allrad	YTD950
Audi	A4 Quattro/Cabriolet Quattro	8E, 8H (B6)	01 - 05	ABS/ESP Allrad	YTD950
Audi	A4 Quattro/Cabriolet Quattro	8E, 8H (B7)	05 -	ESP 8 Allrad	YTD950
Audi	A6	4B (C5)	98 - 01	ABS/ESP Front	YTD950
Audi	A6	4B (C5)	02 - 04	ABS/ESP Front	YTD950
Audi	A6	4F (C6)	05 -	ESP 8 Front	YTD950
Audi	A6 Quattro	4B (C5)	98 - 01	ABS/ESP Allrad	YTD950
Audi	A6 Quattro	4B (C5)	02 - 04	ABS/ESP Allrad	YTD950
Audi	A6 Quattro	4F (C6)	05 -	ESP 8 Allrad	YTD950
Audi	A8	4D (D2)	97 - 03	ABS/ESP Front / Allrad	YTD950
Audi	A8	4E (D3)	03 -	ESP 5.7 Allrad	YTD950
Audi	A8 Quattro	4D (D2)	97 - 03	ABS/ESP Front / Allrad	YTD950
Audi	A8 Quattro	4E (D3)	03 -	ESP 5.7 Allrad	YTD950
Audi	Allroad Quattro (A6 4X4)	4B (C5)	01 - 04	ABS/ESP Allrad	YTD950
Audi	Q7	4L (7L)	07 -	ESP Allrad MK25E1	YTD950
Audi	RS6	4B (C5)	03 - 04	ABS/ESP Allrad	YTD950
Audi	RS6	4B (C5)	03 - 04	ESP 5.7 RS	YTD950
Audi	S3 Quattro	8L	97 - 02	ESP 20	YTD950
Audi	S3 Quattro	8L	02 - 03	ESP Allrad MK60	YTD950
Audi	S3 Quattro	8P	04 -	ESP Allrad MK60	YTD950
Audi	S4	8D (B5)	97 - 00	ABS/ESP Allrad	YTD950
Audi	S4	8E, 8H (B7)	05 -	ESP 8 Allrad	YTD950
Audi	S8	4D (D2)	01 - 03	ABS/ESP Front / Allrad	YTD950
Audi	S8	4E (D3)	03 -	ESP 5.7 Allrad	YTD950
Audi	TT/Coupe	8J	07 -	ESP Front/Allrad MK60	YTD950
Audi	TT/Quattro	8N	99 - 02	ESP 20	YTD950
Audi	TT/Quattro	8N	02 - 06	ESP Front/Allrad MK60	YTD950
Bentley	Continental GT		04 -	Bosch 5.7 ESP	YTD950
Bentley	Flying Spur		05 -	Bosch 5.7 ESP	YTD950
BMW	1 Series - 4 Cylinder	E81/E87	04 - 03/07	Teves MK 60E	YTD960
BMW	1 Series - 6 Cylinder	E81/E87	04 - 03/07	Teves MK 60E5	YTD960
BMW	3 Series	E46	98 - 05	Teves DSC III MK 60	YTD957 or YTD951 A6 / YTD960
BMW	3 Series - 4 Cylinder	E90/E91/E92/E93	05 - 03/07	Teves MK 60E	YTD960
BMW	3 Series - 6 Cylinder	E90/E91/E92/E93	05 - 03/07	Teves MK 60E5	YTD960
BMW	3 Series - AWD	E90/E91/E92/E93	05 - 03/07	Bosch ABS DSCS8 Plus	YTD960

FASTCHECK SAS - Steering Angle Sensor

Make	Model	Body/Chassis	From/To	System	Harness Required
BMW	5 Series	E39	96 - 04	ABS/DSC 5.7	YTD957 or YTD951 A6 / YTD960
BMW	5 Series	E60/E61	04 - 09/05	Bosch ABS DSC8	YTD960
BMW	5 Series	E60/E61	09/05 - 03/07	Bosch ABS DSCS8 Plus	YTD960
BMW	M5	E60	04 - 03/07	Teves MK 60E5	YTD960
BMW	6 Series	E63/E64	05 - 09/05	Bosch ABS DSC8	YTD960
BMW	6 Series	E63/E64	09/05 - 03/07	Bosch ABS DSCS8 Plus	YTD960
BMW	M6	E63/E64	05 - 03/07	Teves MK 60E5	YTD960
BMW	7 Series	E38	94 - 02	BOSCH ABS DSC2, BOSCH ABS DSC3	YTD957 or YTD951 A6 / YTD960
BMW	7 Series	E65/E66	02 - 03/07	ABS/DSC5.7	YTD960
BMW	8 Series	E31	90 - 99	BOSCH ABS DSC2	YTD957
BMW	X3	E83	03 - 03/07	DSC 8 X-Drive	YTD951 A6 / YTD960
BMW	X5	E53	00 - 09/03	ABS/DSC 5.7	YTD951 A6 / YTD960
BMW	X5	E53	09/03 -	DSC 8 X-Drive	YTD951 A6 / YTD960
BMW	Z4	E85/E86	03 - 06	Teves DSC III MK 60	YTD951 A6
BMW	Z4/Z4M	E85/E86	06 - 03/07	DSC MK60E5	YTD951 A6
BMW	Z8	E52	00 - 03	ABS/DSC 5.7	YTD957 or YTD951 A6 / YTD960
Land Rover	Freelander II	L359	07 -	SASM	YTD950 or YTD960
Land Rover	Discovery III	L319	05 -	SAS	YTD950 or YTD960
Land Rover	Range Rover	L322	07 -	SAS	YTD950 or YTD960
Land Rover	Range Rover Sport	L320	05 -	SAS	YTD950 or YTD960
MINI	MINI	R50/R53	00 - 07	Teves DSC III MK 60	YTD951 A6
Seat	Alhambra	7M	96 - 02	ESP 20	YTD950
Seat	Alhambra	7M	02 - 05	ESP Front MK25	YTD950
Seat	Altea with ESP	5P	05 -	ESP Front/Allrad MK60	YTD950
Seat	Altea without ESP	5P	05 -	ABS MK70	YTD950
Seat	Arosa	6H	97 - 02	ESP 20	YTD950
Seat	Arosa	6H	02 - 05	ESP Front MK25	YTD950
Seat	Cordoba	6K	99 - 02	ESP 20	YTD950
Seat	Cordoba	6K/6L	02 - 06	ESP 5.7 Front / Allrad	YTD950
Seat	Cordoba	6L	06 -	ESP 8 Front / Allrad	YTD950
Seat	Ibiza	6K	99 - 02	ESP 20	YTD950
Seat	Ibiza	6K/6L	02 - 06	ESP 5.7 Front / Allrad	YTD950
Seat	Ibiza	6L	06 -	ESP 8 Front / Allrad	YTD950
Seat	Inca	6K	97 - 03	ESP 20	YTD950
Seat	Leon	1M	99 - 02	ESP 20	YTD950
Seat	Leon	1M	02 - 05	ESP Front MK60	YTD950
Seat	Leon with ESP	1P	05 -	ESP Front/Allrad MK60	YTD950
Seat	Leon without ESP	1P	05 -	ABS MK70	YTD950
Seat	Toledo	1M	99 - 02	ESP 20	YTD950
Seat	Toledo	1M	02 - 05	ESP Front/Allrad MK60	YTD950
Seat	Toledo with ESP	5P	05 -	ESP Front/Allrad MK60	YTD950
Seat	Toledo without ESP	5P	05 -	ABS MK70	YTD950
Skoda	Fabia	6Y	99 - 04	ESP 5.7 Front / Allrad	YTD950
Skoda	Fabia	6Y	04 - 07	ESP 8 Front / Allrad	YTD950
Skoda	Octavia	1U	96 - 02	ESP 20	YTD950

FASTCHECK SAS - Steering Angle Sensor

Make	Model	Body/Chassis	From/To	System	Harness Required
Skoda	Octavia	1U	02 - 04	ESP Front / Allrad MK60	YTD950
Skoda	Octavia II with ESP	1Z	04 -	ESP Front / Allrad MK60	YTD950
Skoda	Octavia II without ESP	1Z	04 -	ABS MK70	YTD950
Skoda	Superb	3U	02 - 04	ABS/ESP Front	YTD950
Skoda	Superb II	3T	08 -	ESP Front/Allrad MK60	YTD950
VW	Beetle	1C, 9C, 1Y (A Platform)	98 - 01	ESP 20	YTD950
VW	Beetle	1C, 9C, 1Y (A Platform)	01 -	ESP Front / Allrad MK60	YTD950
VW	Bora	1K2	05 -	ESP Front / Allrad MK60	YTD950
VW	Caddy	2K	04 -	ESP Front / Allrad MK60	YTD950
VW	Eos	1F	05 -	ESP Front / Allrad MK60	YTD950
VW	Fox	5Z1	04 -	ESP 8 Front / Allrad	YTD950
VW	Golf 4motion/R32	1J	98 - 01	ESP 20	YTD950
VW	Golf 4motion/R32	1J	01 - 04	ESP Allrad MK60	YTD950
VW	Golf MK4 / Gti /Rabbit / Bora	6E/6X	98 - 01	ESP 20	YTD950
VW	Golf MK4 / Gti /Rabbit / Bora (US Jetta)	1J	01 - 04	ESP Front MK60	YTD950
VW	Golf MK5 4motion/R32	1K	04 -	ESP Allrad MK60	YTD950
VW	Golf MK5 With ESP	1K	04 -	ESP Front MK60	YTD950
VW	Golf MK5 without ESP	1K	04 -	ABS MK70	YTD950
VW	Golf Plus	5M1	05 -	ESP Front MK60	YTD950
VW	Jetta	1K2	05 -	ESP Front MK60	YTD950
VW	Lupo		99 -	ESP 20	YTD950
VW	Passat	B5 (3B)	97 - 02	ABS/ESP Front	YTD950
VW	Passat	B5 (3B)	02 - 05	ABS/ESP Front	YTD950
VW	Passat	B6 (3C)	05 -	ESP 440 C2	YTD950
VW	Passat 4motion	B5 (3B)	97 - 02	ABS/ESP Allrad	YTD950
VW	Passat 4motion	B5 (3B)	02 - 05	ABS/ESP Allrad	YTD950
VW	Passat 4motion	B6 (3C)	05 -	ESP 440 C2	YTD950
VW	Phaeton	D3 (3D)	03 -	ESP 5.7 Front / Allrad	YTD950
VW	Polo	9N	02 - 05	ESP 5.7 Front	YTD950
VW	Polo	9N	05 -	ESP 8 Front / Allrad	YTD950
VW	Polo	9N	05 -	ESP Front MK60	YTD950
VW	Sharan	7M	98 -	ESP 20	YTD950
VW	Touareg	7L	03 - 06	ESP Allrad MK25	YTD950
VW	Touareg	7L	03 - 06	ESP Allrad MK60	YTD950
VW	Touareg	7L	07 -	ESP Allrad MK25	YTD950
VW	Touran	1T	05 -	ESP Front/Allrad MK60	YTD950
VW	Transporter	7D, 70	96 - 03	ESP 5.3 T4 front	YTD950
VW	Transporter T5	7H, 7J	03 -	ESP Front/Allrad MK25/MK25E1	YTD950

FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
Alfa Romeo	147 (Mannesman VDO instrument panel)	00 - 07		YTD959
Alfa Romeo	159 (Siemens 2 Instrument panel)	05 -		YTD950 or YTD959
Alfa Romeo	GT (Mannesman VDO instrument panel)	04 -		YTD959
Audi	80/Cabrio/Coupe/Quattro	94 - 96	KWP1281	YTD952
Audi	A2	00 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	96 - 04	KWP1281/KW2000	YTD951 A1
Audi	A3	04 -	CAN	YTD950
Audi	A4	95 - 04	KWP1281/KW2000	YTD951 A1
Audi	A4	04 -	CAN	YTD950
Audi	S4	92 - 02	KWP1281/KW2000	YTD952
Audi	S4	04 -	CAN	YTD950
Audi	A6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	A6	04 -	CAN	YTD950
Audi	S6	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S6	04 -	CAN	YTD950
Audi	Allroad Quattro	01 - 04	KWP1281/KW2000	YTD951 A1
Audi	Q7	06 -	CAN	YTD950
Audi	A8	94 - 04	KWP1281/KW2000	YTD951 A1
Audi	A8	04 -	CAN	YTD950
Audi	S8	97 - 04	KWP1281/KW2000	YTD951 A1
Audi	S8	04 -	CAN	YTD950
Audi	TT	00 - 07	KWP1281/KW2000	YTD951 A1
Audi	TT	07 -	CAN	YTD950
Audi	100	94 - 97	KWP1281/KW2000	YTD952
BMW	1 Series (E81/E87)	04 - 03/07	CBS	YTD960
BMW	1 Series (E81/E87)	04 - 03/07	Annual distance	YTD960
BMW	1 Series (E81/E87)	04 - 03/07	Battery change	YTD960
BMW	3 Series (E30)	88 - 91	Analogue	YTD957
BMW	3 Series (E36)	91 - 99	Analogue	YTD957 or YTD951 A2/F2
BMW	3 Series (E46)	98 - 05	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	CBS	YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	Annual distance	YTD960
BMW	3 Series (E90/E91/E92/E93)	05 - 03/07	Battery change	YTD960
BMW	5 Series (E34)	88 - 97	Analogue	YTD957
BMW	5 Series (E39)	97 - 03	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	5 Series (E60/E61)	04 - 03/07	CBS	YTD960
BMW	5 Series (E60/E61)	04 - 03/07	Annual distance	YTD960
BMW	5 Series (E60/E61)	04 - 03/07	Battery change	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	CBS	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	Annual distance	YTD960
BMW	6 Series (E63/E64)	05 - 03/07	Battery change	YTD960
BMW	7 Series (E38)	95 - 02	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	7 Series (E65)	02 - 03/07	CBS	YTD960
BMW	7 Series (E65)	02 - 03/07	Annual distance	YTD960
BMW	7 Series (E65)	02 - 03/07	Battery change	YTD960

FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
BMW	8 Series (E31)	91 - 97	Analogue	YTD957 or YTD951 A2/F2
BMW	X3 (E83)	03 -	Digital	YTD951 A2/F2
BMW	X5 (E53)	00 -	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	Z3 (E36)	96 - 02	Digital or Analogue	YTD957 or YTD951 A2/F2
BMW	Z4 (E85)	03 -	Digital	YTD951 A2/F2
BMW	Z8 (E52)	99 - 04	Analogue	YTD957
Fiat	Croma 05 (Marelli 2)	05 -		YTD950 or YTD959
Fiat	Idea (Marelli instrument panel - comfort)	04 -		YTD959
Fiat	Palio RST2 (Marelli instrument panel - Palio RST2)	02 -		YTD959
Fiat	Panda 03 (Marelli instrument panel)	03 -		YTD959
Fiat	Punto 03 (Marelli instrument panel - comfort)	03 - 05		YTD959
Fiat	Stilo (Visteon instrument panel)	01 -		YTD959
Ford	Galaxy (with VW engine)	95 - 00		YTD951 A1
GM	Agila	00 - 08	InstAgil	YTD951 J2
GM	Astra-G	98 - 04	Instr30	YTD951 J2
GM	Astra-H	04 -	CAN IPC	YTD960
GM	Corsa-C	01 - 06	Instr43	YTD951 J2
GM	Corsa-D	06 -	CAN IPC	YTD960
GM	Meriva	03 - 08	Instr43	YTD951 J2
GM	Signum	01 -	CAN IPC	YTD960
GM	Signum	01 -	Long-Life Oil Reset	YTD950 or YTD960
GM	Tigra-B	05 - 08	Instr43	YTD951 J2
GM	Vectra-C	01 -	CAN IPC	YTD960
GM	Vectra-C	01 -	Long-Life Oil Reset	YTD950 or YTD960
GM	Zafira-A	98 - 05	Instr30	YTD951 J2
GM	Zafira-B	05 -	CAN IPC	YTD951 J2
Lancia	Musa (Marelli instrument panel - comfort)	04 -		YTD959
Lancia	Thesis (Nippon Seiki instrument panel)	02 -		YTD959
Lancia	Ypsilon (Siemens instrument panel)	03 -		YTD959
Land Rover	Freelander II (359)	07 -	Service Reset	YTD960
Land Rover	Discovery III (L319)	05 -	Service Reset	YTD950 or YTD960
Land Rover	Range Rover (L322)	07 -	Service Reset	YTD950 or YTD960
Land Rover	Range Rover Sport (L320)	05 -	Service Reset	YTD950 or YTD960
Mercedes	A Class (W169)	04 -	Assyst Plus	YTD950
Mercedes	B Class (W245)	05 -	Assyst Plus	YTD950
Mercedes	C Class (W202)	96 - 00	FSS	YTD951 C2 and YTD956
Mercedes	C Class (W203)	00 - 03	FSS	YTD951 B2
Mercedes	CL (W215)	99 - 00	FSS	YTD951 C2 and YTD956
Mercedes	CL (W215)	00 - 05	FSS	YTD951 B2/C2
Mercedes	CLK (W208)	98 - 04	FSS	YTD951 C2 and YTD956
Mercedes	CLS (W219)	04 -	Assyst Plus	YTD950
Mercedes	E Class (W210)	96 - 02	FSS	YTD951 C2 and YTD956
Mercedes	E Class (W211)	02 -	Assyst Plus	YTD950
Mercedes	ML (W163)	97 - 05	FSS	YTD951 C2
Mercedes	ML (W164)	05 -	Assyst Plus	YTD950

FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
Mercedes	R Class (V251)	05 -	Assyst Plus	YTD950
Mercedes	S Class (W140)	97 - 99	FSS	YTD951 C2 and YTD956
Mercedes	S Class (W220)	99 - 05	FSS	YTD951 B2/C2
Mercedes	S Class (W221)	05 -	Assyst Plus	YTD950
Mercedes	SL (R129)	95 - 02	FSS	YTD951 C2/J2 and YTD956
Mercedes	SL (R230)	01 - 03	FSS	YTD951
Mercedes	SLK (R170)	98 - 01	FSS	YTD951 C2/J2 (and YTD956 if no J1962*)
Mercedes	SLK (R171)	04 -	Assyst Plus	YTD950
Mercedes	Sprinter (W901 / W902 / W903 / W904)	95 - 02	FSS	YTD951 C2/J2 (and YTD955 if no J1962*)
MG Rover	75	99 - 02		YTD951 F6 or F2
MINI	MINI (R50 / R53)	00 - 07		YTD951 F2
Saab	9-3	98 - 02		YTD951 A1
Saab	9-5	97 - 02		YTD951 A1
Seat	Alhambra	96 -	KWP1281 / KW2000	YTD951 A1
Seat	Altea	04 -	CAN	YTD950
Seat	Arosa	97 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Cordoba	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Ibiza	93 -	KWP1281 / KW2000	YTD951 A1
Seat	Leon	00 - 04	KWP1281 / KW2000	YTD951 A1
Seat	Leon	04 -	CAN	YTD950
Seat	Toledo	92 - 05	KWP1281 / KW2000	YTD951 A1
Seat	Toledo III	04 -	CAN	YTD950
Skoda	Fabia	00 - 07	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Fabia II	07 -	CAN	YTD950
Skoda	Octavia	96 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
Skoda	Octavia II	04 -	CAN	YTD950
Skoda	Superb	02 -	KWP1281 / KW2000	YTD952 or YTD951 A1
Volvo	850	93 - 97		YTD951 A1 or YTD954
Volvo	S40	97 - 98		YTD951 A1
Volvo	V40	97 - 98		YTD951 A1
Volvo	S70	97 - 98		YTD951 A1
Volvo	V70	97 - 98		YTD951 A1
VW	Beetle	99 -	KWP1281 / KW2000	YTD951 A1
VW	Bora	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Bora	05 -	CAN	YTD950
VW	Cabrio	95 - 02	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	92 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Caddy	05 -	CAN	YTD950
VW	Corrado	91 - 95	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	EOS	05 -	CAN	YTD950
VW	Eurovan	99 - 03	KWP1281 / KW2000	YTD950
VW	Golf/GTI	92 - 03	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Golf/GTI	03 -	CAN	YTD950
VW	Golf Plus	05 -	CAN	YTD950
VW	Jetta	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1

FASTCHECK SERVICE

Make	Model	From/To	System	Harness Required
VW	Jetta	05 -	CAN	YTD950
VW	Lupo	98 - 05	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	94 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Passat	05 -	CAN	YTD950
VW	Phaeton	03 -	KWP1281 / KW2000	YTD951 A1
VW	Polo	98 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Touareg	03 - 06	KWP1281 / KW2000	YTD951 A1
VW	Touareg	07 -	CAN	YTD950
VW	Touran	03 -	CAN	YTD950
VW	Sharan	95 -	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle	92 - 04	KWP1281 / KW2000	YTD952 or YTD951 A1
VW	Transporter/Caravelle T5	04 -	CAN	YTD950
VW	Vento	92 - 98	KWP1281 / KW2000	YTD950

*NOTE: The CAN variable service reset will only work with the EOBD harness YTD950, the switchable harness YTD951 should not be used.

FASTCHECK TPMS

Make	Model	From/To	System	Harness Required
Citroen	C4	04 -	Schrader TPMS	YTD950 and YTD964
Citroen	C5	99 - 05	Schrader TPMS	YTD951 I1
Citroen	C5 II	04 -	Schrader TPMS	YTD950 and YTD964
Citroen	C6	06 -	Schrader TPMS	YTD950 and YTD964
Citroen	C8	02 -	Schrader TPMS	YTD951 I1
Fiat	Ulysse	94 - 05	Schrader TPMS	YTD951 I1
Ford	Explorer	04 -	TPMS	YTD950 or YTD960
Ford	Focus	04 -	TPMS	YTD950 or YTD960
Ford	Focus C-Max	03 -	TPMS	YTD950 or YTD960
Ford	Expedition	05 -	TPMS	YTD950 or YTD960
GM	Vectra-C	02 -	TPMS	YTD960
GM	Signum	02 -	TPMS	YTD960
GM	Astra-H	04 -	TPMS	YTD960
GM	Zafira-B	05 -	TPMS	YTD960
Lancia	Phedra	02 - 06	Schrader TPMS	YTD951 I1
Land Rover	Discovery III (L319)	05 -	TPMS	YTD960
Land Rover	Range Rover (L322)	07 -	TPMS	YTD960
Land Rover	Range Rover Sport (L320)	05 -	TPMS	YTD960
Peugeot	307 II	05 -	Schrader TPMS	YTD950 and YTD964
Peugeot	407	04 -	Schrader TPMS	YTD950 and YTD964
Peugeot	607	99 -	Schrader TPMS	YTD951 I1
Peugeot	607 II	04 -	Schrader TPMS	YTD950 and YTD964
Peugeot	807	02 -	Schrader TPMS	YTD951 I1
Renault	Espace IV	03 -	Central Body Electrics - Renault TPMS	YTD950 or YTD951 A1
Renault	Laguna II	00 -	Central Body Electrics - Renault TPMS	YTD950 or YTD951 A1
Renault	Megane II	02 -	Central Body Electrics - Renault TPMS	YTD950
Renault	Scenic II	03 -	Central Body Electrics - Renault TPMS	YTD950
Renault	Vel Satis	00 -	Central Body Electrics - Renault TPMS	YTD950 or YTD951 A1